# Always there to help you

Register your product and get support at www.philips.com/welcome



AZ320/12



# User manual



# Contents

1	Important Safety Notice	3 3 3
2	Your CD Soundmachine Introduction What's in the box Overview of the main unit	5 5 5 5
3	Get started Connect power Turn on Turn off	6 6 7 7
4	Play Play a CD Play from USB devices Tune to FM radio stations Play from an external device	8 8 8 9 9
5	Play options Control play Program tracks Adjust sound	10 10 10 10
6	Product information Specifications Supported MP3 disc formats USB playability information Maintenance	11 11 11 11 12
7	Troubleshooting	12

## 1 Important

## Safety

- Read these instructions.
- Follow all instructions.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the unit.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this unit during lightning storms or when unused for long periods of time.
- Recording is permissible insofar as copyright or other rights of third parties are not infringed upon.
- Refer all servicing to qualified service personnel. Servicing is required when the unit has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the unit has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Battery usage CAUTION To prevent battery leakage which may result in bodily injury, property damage, or damage to the unit:
  - Install all batteries correctly, + and as marked on the unit.
  - Do not mix batteries (old and new or carbon and alkaline, etc.).
  - Remove batteries when the unit is not used for a long time.

- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
- CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- The unit shall not be exposed to dripping or splashing.
- Do not place any sources of danger on the unit (e.g. liquid filled objects, lighted candles).
- Where the MAINS plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.



#### Warning

- · Never remove the casing of this apparatus.
- Never place this apparatus on other electrical equipment.
- Never look into the laser beam inside this apparatus.



#### Caution

 Use of controls or adjustments or performance of procedures other than herein may result in hazardous radiation exposure or other unsafe operation.

## **Notice**



This product complies with the radio interference requirements of the European Community.

Any changes or modifications made to this device that are not expressly approved by Philips Consumer Lifestyle may void the user's authority to operate the equipment.



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/FC

Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste. Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health



Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed with normal household waste. Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environmental and human health.

#### Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), paper pulp (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

### This apparatus includes these labels:



Class II equipment symbol



This symbol indicates that the apparatus has a double insulation system.



The making of unauthorized copies of copyprotected material, including computer programs, files, broadcasts and sound recordings, may be an infringement of copyrights and constitute a criminal offence. This equipment should not be used for such purposes.



The USB-IF Logos are trademarks of Universal Serial Bus Implementers Forum, Inc.



Windows Media and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.



 The type plate is located on the bottom of the apparatus.

# 2 Your CD Soundmachine

## Introduction

With this CD Soundmachine, you can:

- listen to FM radio:
- enjoy audio from discs, USB device, and other external audio devices;
- program the play sequence of tracks.


The unit offers you Dynamic Bass Boost (DBB) to enrich sound.


## What's in the box

Check and identify the contents of the package:

- Main unit
- Quick start guide
- Safety sheet

## Overview of the main unit





- (1) DBB
  - Turn dynamic bass boost on/off.
  - Stop playing.
- 2 ALBUM +
  - Skip to the previous or next album.
- (3) |◀◀ / ▶▶|
  - Skip to the previous or next track.
  - Search within a track.
- 4 OPEN•CLOSE
  - Open or close the disc compartment.
  - Start or pause play.
  - Press to wake up the unit from standby mode.
- (5) PROG
  - Program the play sequence of tracks.
- 6 MODE
  - Select a play mode.
- 7 Display panel
  - Display current status.
- (8) FM antenna

- Improve FM reception.
- 9 + TUNING -
  - Tune to FM radio stations.
- (10) 🗠
  - USB socket.
- (11) Source selector
  - · Select a source.
- 12) + VOLUME -
  - Adjust volume
- (13) AUDIO-IN
  - Connect an external audio device.

## 3 Get started



#### Caution

 Use of controls or adjustments or performance of procedures other than herein may result in hazardous radiation exposure or other unsafe operation.

Always follow the instructions in this chapter in sequence.

If you contact Philips, you will be asked for the model and serial number of your apparatus. The model number and serial number are on the bottom of your apparatus. Write the numbers here:

Model No. \_\_\_\_\_\_ Serial No. \_\_\_\_\_

## Connect power

The unit can be powered by either AC power or batteries.

## Option 1:AC power



### Warning


- Risk of product damage! Make sure that the power supply voltage corresponds to the voltage printed on the back or the underside of the unit.
- Risk of electric shock! When you disconnect the AC power, always pull the plug from the socket. Never pull the cord.

Connect the AC power cord to the wall socket.



#### Пр

· To save energy, turn the unit off after use.



## Option 2: Battery power




#### Caution

 Batteries contain chemical substances, so they should be disposed of properly.



#### Note

- · Batteries are not supplied with the accessories.
- 1 Open the battery compartment.
- 2 Insert 6 batteries (type: 1.5V R14/UM2/C CELL) with correct polarity (+/-) as indicated.
- 3 Close the battery compartment.



## Turn on

Switch the source selector on the main unit to FM/USB/AUDIO-IN/CD.

When the source selector is in the AUDIO-IN/CD position, CD is displayed.

#### Switch to standby mode

- The unit switches to standby mode automatically when there is no audio detected for over 15 minutes.
- Press ►II to wake up the unit from standby mode.

## Turn off

Switch the source selector on the main unit to **OFF**.

# 4 Play

## Play a CD




#### Note

- You cannot play CDs encoded with copyright protection technologies.
- When an audio-in cable is plugged, CD/USB playback stops, and the unit switches to audio in mode automatically.

You can play commercially available audio CDs:

- CD-Recordables (CD-R)
- CD-Rewritables (CD-RW)
- MP3-CDs
- 1 Switch the source selector to CD.
- 2 Open the CD compartment.
- Insert a CD with the printed side facing up and close the CD lid gently.
  - → The total number of tracks displays.
  - → Your CD sound machine starts to play automatically.
- To select a track, press ◄◄ / ▶▶I.
- To pause CD play, press ►II.
  - $\rightarrow$  [ $\triangleright$ ] flashes.
- To resume CD play, press ► II again.
- To stop CD play, press ■.




## Play from USB devices



#### Note

- Make sure that the USB device contains playable audio content.
- 1 Switch the source selector to **USB**.
- 2 Insert the USB device into the ← socket.
  - → Play starts automatically. If not, press




## Tune to FM radio stations



Note

- For optimal reception, fully extend and adjust the position of the FM antenna.
- 1 Switch the source selector to FM.
- 2 Rotate **TUNING** to select a station.
- **3** Repeat step 2 to tune to more stations.





## Play from an external device


You can also listen to an external audio device through this unit.

- 1 Switch the source selector to AUDIO-IN/CD.
- 2 Connect an audio cable (3.5mm, not supplied) to:
  - the AUDIO-IN socket on the unit.
  - the headphone socket on an external device.
- 3 Play the external device (see the device's user manual).



Note

- The AUDIO-IN socket is not for headphones.
- The display panel lights off when the unit plays from the external device.



# 5 Play options

## Control play

In CD mode, you can control play through the following operations.

<b> </b> ◀◀ / ▶▶	Press:skip to the previous/next track
	Hold:search within play, then
	release to resume play.
►II	Start or pause play.
	Stop play.
PROG	Program tracks.
+VOLUME-	Adjust volume.
- ALBUM +	Skip the the previous or next
	album.
MODE	Select a play mode.
	[ 🌣 ]: Play the current track
	repeatedly.
	[ 🗘 ALL ]: Play all tracks
	repeatedly.
	[ ☎ ⇔ALL ]: Repeat all tracks
	randomly.
	To return to normal play, press
	MODE repeatedly until the
	repeat icons disappear.



• Only [ ] and [ ALL ] can be selected when you play the programmed tracks.

## Program tracks

In CD and USB mode, you can program a maximum of 20 tracks.

- 1 Press to stop playback.
- 2 Press **PROG** to activate the program mode.
  - → [PROG] (program) begin to blink.
- 3 Press I◀◀ / ▶▶I to select a track number, then press PROG to confirm.
- **4** Repeat steps 3 to program more tracks.
- 5 Press ►II to play the programmed tracks.
  - → During play, [PROG] (program) is displayed.
  - To erase the program, press twice.

## Adjust sound

During play, you can adjust volume and select the sound effects.

Key	Function	
+VOLUME-	Increase or decrease volume.	
DBB	Turn dynamic bass	
	enhancement on or off.	

# 6 Product information



 Product information is subject to change without prior notice.

## **Specifications**

Amplifier			
Max Output Power	Total 2 W RMS		
Frequency Response	63 -20000 Hz, -3dB		
Signal to Noise Ratio	>57 dBA		
Total Harmonic Distortion	<1 %		
Audio-in Input	650 mV RMS		

Disc			
LaserType	Semiconductor		
Disc Diameter	12cm/8cm		
Support Disc	CD-DA, CD-R, CD- RW, MP3-CD		
Audio DAC	24Bits / 44.1kHz		
Total Harmonic	<1%		
Distortion			
Frequency Response	63 -20000 Hz, -3dB		
S/N Ratio	>57 dBA		

Tuner			
Tuning Range	87.5 - 108MHz		
Total Harmonic Distortion	<3%		
Signal to Noise Ratio	>50 dBA		

General			
Power supply - AC Power	220-240V~, 50/60 Hz;		
- Battery	9 V, 6 × 1.5 V		
	type: R14/UM2/C CELL		
Operation Power	15 W		
Consumption			
Standby Power	<0.5 W		
Consumption			
Dimensions	299 × 240 × 132		
- Main Unit ( $W \times H \times D$ )	mm		
Weight (Main Unit)	1.5 kg		

## Supported MP3 disc formats

- ISO9660, Joliet
- Maximum title number: 512 (depending on file name length)
- Maximum album number: 255
- Supported sampling frequencies: 32 kHz, 44.1kHz, 48 kHz
- Supported Bit-rates: 32~256 (kbps), variable bit rates

## USB playability information

#### Compatible USB devices:

- USB flash memory (USB 2.0 or USB1.1)
- USB flash players (USB 2.0 or USB1.1)
- memory cards (requires an additional card reader to work with this apparatus)

#### Supported formats:

- USB or memory file format FAT12, FAT16, FAT32 (sector size: 512 bytes)
- MP3 bit rate (data rate): 32-320 Kbps and variable bit rate
- Directory nesting up to a maximum of 8 levels

- Number of albums/ folders: maximum
   99
- Number of tracks/titles: maximum 999
- ID3 tag v2.0 or later
- File name in Unicode UTF8 (maximum length: 128 bytes)

#### Unsupported formats:

- Empty albums: an empty album is an album that does not contain MP3/ WMA files, and is not be shown in the display.
- Unsupported file formats are skipped. For example, Word documents (.doc) or MP3 files with extension .dlf are ignored and not played.
- AAC, WAV, PCM audio files

## Maintenance

#### Clean the cabinet

 Use a soft cloth slightly moistened with a mild detergent solution. Do not use a solution containing alcohol, spirits, ammonia or abrasives.

#### Clean discs

 When a disc becomes dirty, clean it with a cleaning cloth. Wipe the disc from the centre out.



 Do not use solvents such as benzene, thinner, commercially available cleaners, or antistatic spray intended for analogue records.

#### Clean the disc lens

 After prolonged use, dirt or dust may accumulate at the disc lens. To ensure good play quality, clean the disc lens with Philips CD lens cleaner or any commercially available cleaner. Follow the instructions supplied with cleaner.

# 7 Troubleshooting



#### Warning

· Never remove the casing of this device.

To keep the warranty valid, never try to repair the system yourself.

If you encounter problems when using this device, check the following points before requesting service. If the problem remains unsolved, go to the Philips Web page (www. philips.com/support). When you contact Philips, make sure that the device is nearby and the model number and serial number are available. No power

- Ensure that the Mains cord is connected securely.
- Ensure that there is power at the AC Mains.
- Ensure that the batteries are inserted correctly.

#### No sound or poor sound

Adjust the volume.

#### No response from the unit

- Disconnect and reconnect the AC power plug, then turn on the system again.
- As a power-saving feature, the unit switches off automatically 15 minutes after track play reaches the end and no control is operated.

#### No disc detected

- Insert a disc.
- Check if the disc is inserted upside down.
- Wait until the moisture condensation at the lens has cleared.
- Replace or clean the disc.
- Use a finalized CD or correct format disc.

#### Poor radio reception

- Increase the distance between the unit and yourTV orVCR.
- Fully extend the FM antenna.



Specifications are subject to change without notice © 2013 Koninklijke Philips Electronics N.V. All rights reserved.

